AP900Ci Cruise Control Installation Manual
Fiat Doblo, model years 2010–2015

1. Connect the throttle control wires to the connector located near the accelerator pedal.

2. Select a suitable location for the control unit inside the passenger compartment.

3. Install the CM35 command module in the steering column cover by drilling a 10 mm diameter hole.

Drill the hole carefully to avoid damaging any components located inside the steering column cover. After installing the command module, insert the wires into the connector housing according to the wire colours marked on the housing.

**Warning: Do not operate the device by placing your hand between the spokes of the steering wheel.**

4. Connect by soldering the blue CAN HIGH wire to pin 6 of the OBD connector – green wire.
5. Connect by soldering the blue-white CAN LOW wire to pin 14 of the OBD connector – brown wire.
6. Connect the orange wire to a switched +12 V power supply. The voltage must not drop out while the engine is being started.

-For example, the ignition connector (wiring harness) – blue wire.

-The second option is the ISO connector behind the radio, connector A, pin 7 (blue-green wire).

**Note: The ground connection is supplied through the throttle control wiring.**

7. Perform the calibration procedure.
8. Carry out a road test.
9. Insulate all unused wires.
10. Enjoy using the device.

For technical support, call: +48 515 601 431